



Solinst Water Level Meter



The water-sensing probe is attached to a 300-foot polyethylene flat tape with permanent markings every 1/100 of a foot. A dial allows the buzzer to be adjusted or turned off when the probe is in cascading water and ensures a clear signal when the probe contacts high or low conductivity water. The tape is wound on a 10-inch diameter plastic reel with a brake.

Use:

Measure depth to water in wells, boreholes, and shafts.

Check out Contact information:

The water level meter is available from the Technical Services Branch of the Mid-Continent Region. Contact **Brian Hicks** at **618-463-6463 ext. 5121** or **bhicks@osmre.gov**.